

## TO USE ONE TOUCH KEYS

- Press one touch speed dial key.
- Number is automatically dialed.

## TO PROGRAM STATION SPEED DIAL

Display sets only.

- Press **SPEAKER** key.
- Enter **755** followed by the station speed dial location (**0-9**).
- Dial **9** + **telephone number**.
- Press **HOLD**.
- Enter name if desired.
- Press **HOLD**.
- Press **SPEAKER** key to hang up.

## TO USE STATION SPEED DIAL

- Press the **SPEAKER** key.
- Press **#7**.
- Dial the station speed dial location (**0-9**).

## **TO SET UP VOICE MAIL**

**Soft Keys are located under the display**

Press **VMsg** soft key  
To Record Greeting:  
Press **Greet** soft key  
Press **Gr1** soft key  
Follow instructions for recording greeting  
Choose Listen, Record or Del, OR  
Press **Done** or **#** when finished  
Press **Back** soft key or **#** when finished  
Press **Back** soft key or **#** again  
This will take you back to Main Menu  
To Record Name:  
Press **More** soft key and **Rec Name** soft key **OR** dial **"76"** to record name  
Follow instructions for recording name  
Choose Listen, Record or Del, OR  
Press **Back** soft key or **#** when finished  
To assign a security code,  
Press **More** soft key and **Set Up** soft key  
key and **Code** soft key **OR** dial **"67"**  
Enter 4-digit code  
Select Required (from your extension) or  
Not required

## TO ACCESS VOICEMAIL

- From your phone press **VMsg** soft key or Message key. Follow prompts.
- From another phone dial **200**. When voice mail answers enter **your extension**. Follow prompts.
- From outside the office, dial **main number**. When the voice mail system answers, enter **#** and **your extension**, enter **security code**. You MUST have a security code to access your mailbox. Follow prompts.
- If call is answered, ask for transfer to Voice Mail. When Voice Mail answers, press **#** and your extension number.

## VOICE MAIL QUICK KEYS

Check new & old messages	5
Leave a message	77
Main menu of features	0
Mailbox Greeting	4
Record Name	76
Time and Date	84
<b>While listening to a message</b>	
Forward a message	63
Save a message	72
Erase a message	3
Listen to next	5
Rewind	2
Repeat	22
Fast forward	4
<b>Mailbox Options</b>	
Security Code	67
Auto Time/Date Stamp	28

## CHANGING HANDSFREE AND RINGING ON INTERNAL CALLS

Dial 721 for hands free  
Dial 723 for ringing

# **NEC SV9100 TELEPHONE & VOICE MAIL USER GUIDE**



## TO ADJUST SPEAKER VOLUME

- While using **SPEAKER**, press top or bottom cursor key.

### TO ADJUST HANDSET VOLUME

- While using handset, press top or bottom cursor key.

### TO ADJUST RING TONE/VOLUME

- Press top or bottom cursor key while phone is ringing OR dial 729 and press top or bottom cursor key.

### TO PLACE A CALL

- Lift handset or press **SPEAKER** key.
- *For internal call* – dial 3-digit extension.
- *For outside call* – dial 9 + telephone number.

### TO ANSWER A CALL

- Lift handset or press **SPEAKER** key.

### TO PLACE CALL ON HOLD

- Press the **HOLD** key.

### TO PLACE CALL ON PARK

- Press the **PARK 1 OR PARK 2** key.

### TO RETRIEVE A CALL ON PARK

- Press the flashing **PARK 1 OR PARK 2** key.

### TO TRANSFER A CALL

- While on a call, press pre-programmed **DSS** key or press **TRANSFER** key and dial the 3-digit extension number.
- Hang up, or supervise call (optional) then hang up.

### DIRECT TRANSFER TO VOICE MAIL

- While on a call, press pre-programmed **DSS** key or press **TRANSFER** key, enter destination extension + **8** and hang up.

- Caller is transferred directly into user's voice mail box.

### ALL CALL/ZONE PAGE

- Lift Handset  
Press the Page All key

### CONFERENCE CALL

- While on a call, press **CONF** key.
- Dial second number you wish to conference.
- When second party answers, press **Add & Begin** (Soft Keys)

### TO TURN MIC ON/OFF (SPEAKER ONLY)

- Press **MIC** key. Red light means microphone is turned on.

### TO MUTE CALL WHILE ON HANDSET

- While connected to caller press the **MIC** button. The button will flash. This will mute you to the caller

### LAST NUMBER REDIAL AND CALLER ID INFORMATION

- Press **LIST soft** key.
- Press **REDIAL** or **CID**
- To search for a desired number in the redial or caller ID list, press the soft keys under the up or down arrow keys in the display; lift handset or press the speaker key to place the call.

### CALL FORWARDING ALL - SET

- Press **FWD ALL** key or dial 741
- Press **1** to set.

- Enter **3-digit** extension or **9 + outside number**.
- Press **SPEAKER**.

### CALL FORWARDING ALL - CANCEL

- Press **FWD ALL** key or dial 741
- Press **0** to cancel.

### CALL PICKUP GROUP

- To pick up another ringing extension within your group, lift handset and press \*#.

### CALL PICKUP DIRECT

- To pick up another ringing extension, lift handset and press \*#.
- Enter extension number and converse with party.

### TO CHANGE RING TONE

- Press **SPEAKER** key.
- Dial **720**.
- Press **1** to set Intercom ring; **2** to set trunk ring.
- Press **1** for TONE or **2** for MELODY
- Select 1 thru 5 to hear tone (You can only hear one tone or melody at a time and must repeat the steps to hear each one.

### TO PROGRAM ONE TOUCH KEYS

- Press **SPEAKER** key.
- Enter Service Code **751**.
- Press one touch key.
- Enter **01** follow by ext. # or 9 + number.
- Press **HOLD**.
- Press **SPEAKER** to hang up.

Soft Keys are located under the display