

TO PROGRAM STATION SPEED DIAL

Display sets only.

- Press **SPEAKER** key.
- Enter **755** followed by the station speed dial location (**0-9**).
- Dial **9 + telephone number**.
- Press **HOLD**.
- Enter name if desired.
- Press **HOLD**.
- Press **SPEAKER** key to hang up.

TO USE STATION SPEED DIAL

- Press the **SPEAKER** key.
- Press **#7**.
- Dial the station speed dial location (**0-9**).

TO SET UP VOICE MAIL

Soft Keys are located under the display
1 = yes and 2 = no

- Press **VMsg** soft key
Enter security code (default = 0000)
System will prompt for the following:
1. Record your name
 2. Enter the 1st three characters of your name
 3. Select directory status YES (1)
 4. Record greeting
 5. Select security code
- Press 1 when finished to confirm mailbox settings* Stay on line until she says great!

TO ACCESS VOICEMAIL

- From your phone press **VMsg** soft key
- Enter security code
- Use soft keys (located under display) to listen to new/old messages, leave messages,
- From another phone press vmmsg & #.
When voice mail answers enter 9 + **your extension**. Follow prompts.

- From outside the office, dial **main number**.
When the voice mail system answers, enter 9 and **your extension**. Follow prompts.
- If call is answered, ask for transfer to Voice Mail (X1xxx) When Voice Mail answers, press 9 and your extension number.

VOICE MAIL QUICK KEYS

Check new	4
Leave a message	5
Check old messages	6
Set up options	7
Switch personal greetings	745
Change standard greeting	746
Change alternate greeting	747

While listening to a message from outside the office, enter 3 to hear menu options or immediately press the following to select an action

Repeat the message	3#
Save message as new	30
Check the next message	35
Delete message	36
Archive message	37
Time Stamp	38
Redirect message	39

If the message has finished playing you can drop the 3 for the above features

Message playback options	
Skip to end of message	1
Skip to end of message, do not hear	
Caller ID or time stamp	3
Rewind	7
Pause	8
Forward	9
Repeat	#
Save as new	*

NEC SV9100 TELEPHONE & VOICE MAIL USER GUIDE

Soft Keys



Cursor

TO ADJUST SPEAKER VOLUME

- While using **SPEAKER**, press top or bottom cursor key.

TO ADJUST HANDSET VOLUME

- While using handset, press top or bottom cursor key.

TO ADJUST RING TONE/VOLUME

- Press top or bottom cursor key while phone is ringing OR dial 729 and press top or bottom cursor key.

TO PLACE A CALL

- Lift handset or press **SPEAKER** key.
- *For internal call* – dial 3-digit extension.
- *For outside call* - dial 9 + telephone number

TO ANSWER A CALL

- Lift handset or press **SPEAKER** key or press flashing **ANSWER** key.

TO MUTE A SPEAKERPHONE CALL

- Press **MIC** key to turn off the red light.

TO MUTE A HANDSET CALL

- Press the **MIC** key to make the red light flash.

TO PLACE CALL ON HOLD

- Press the red **HOLD** key.

TO TRANSFER A CALL

- While on a call, press preprogrammed **DSS** key or press **Transfer** key and dial the 3 - digit extension number or 9 plus outside #.
- Hang up or supervise call (optional) then hang up to complete the transfer.

DIRECT TRANSFER TO VOICE MAIL

- While on a call, press **TRANSFER** key, enter destination extension + **8** and hang up.
- Caller is transferred directly into user's voice mail account.

CALL PARK SET

- While connected to a call, press the **PARK 1, PARK 2, PARK 3 or PARK 4** key

CALL PARK PICK UP

- Lift the handset and press the flashing **PARK 1, 2, 3 or 4** key

CONFERENCE CALL

- While on a call, press **CONF** key (soft key in display).
- Dial second number you wish to conference.
- When second party answers, press **ADD & BEGIN** (soft keys)

CHANGING YOUR ICM CALL MODE

- To have your phone ring on ICM dial 723
- For hands free ICM dial 721

LAST NUMBER REDIAL

- Press **REDIAL** key. Display shows last number dialed.
- Press **#** key to redial number.
- To search for a desired number in the redial list, press the up or down arrow keys in the display; lift handset to place the call.

SCROLLING CALLER ID AND REDIAL

- Press the **LIST** soft key
- Press **REDIAL** or **CID**
- Use the Up/Down arrows to scroll
- Press the speaker key or lift handset to dial desired number.

CALL FORWARDING ALL - SET

- Press **FWD ALL** key or dial 741.
- Press **1** to set.
- Enter **3-digit** extension or **9 + outside number**.
- Press **SPEAKER**.

CALL FORWARDING ALL – CANCEL

- Press **FWD ALL** key or dial 741.
- Press **0** to cancel.

CALL PICKUP DIRECT

- To pick up another ringing extension, lift handset and press the **DIR PICK** key or dial **.
- Enter extension number and converse with party.

CALL PICKUP GROUP

To pick up another ringing extension, lift handset and press the **PICK UP** key or dial *#.

TO PROGRAM ONE TOUCH KEYS

- Press **SPEAKER** key.
 - Enter Service Code **751**.
 - Press one touch key.
 - Enter **01** follow by ext or 9 + number.
 - Press **HOLD**.
- Press **SPEAKER** to hang up.

TO USE ONE TOUCH KEYS

- Press one touch speed dial key.
- Number is automatically dialed.

Soft Keys are located under the display